

Speaker Selector

PS-6116



Speaker Selector

PS-6116



Make certain that speakers and input sources are properly connected before switching the unit on.

Keep volume levels turned down before switching on.

- **16 ZONE SPEAKER SELECTOR**

- 19 push type selector switches are provided to enable you to select 16 zone speakers individually or totally.

- **EASY CONFIRMING**

- You can confirm selected zone and the operating mode of system by using label holder and indicating LED on the front panel.


- **ALL SWITCH**

- You can select all zone speakers use by one switch.

- **GROUP 1, GROUP 2 SWITCH**

- You can select group 1 speakers(CH1~8) or Group 2 (CH9~16) by individual group switches.

FRONT/REAR PANEL




- 1 ALL SWITCH
- 2 GROUP 1, GROUP 2 SWITCH
- 3 OPERATING MODE INDICATORS
- 4 1-16 SPEAKER SELECTOR SWITCH




- 1 DC INPUT TERMINALS
- 2 16 SPEAKER OUTPUT TERMINALS
- 3 AMP INPUT TERMINALS
- 4 REMOTE CONTROL TERMINALS
- 5 TIMER, REMOTE CONTROL INDICATOR TERMINALS
- 6 SPEAKER OUTPUT TERMINALS

APPLICATIONS




BLOCK DIAGRAM



SPECIFICATIONS

		PS-6116
ELECTRICAL	Speaker Selection	16 Channels, All, Group 1, Group 2
	Indicators	16 Channels, All, Group 1, Group
		Timer Mode, Remote Mode
GENERAL	Power Source	24V DC
	Weight	3.3kg/7.27lb
	Dimensions	482(W)x44(H)x280(D)mm/19(W)x1.7(H)x11(D)in

DIMENSIONS





Inter-M Corp. (IMK)

719, Dobong-ro, Dobong-gu, Seoul, Korea
Overseas Sales Team

Tel_ +82-2-2289-8141~7 Fax_ +82-2-2289-8149 E-mail_ overseas@inter-m.com

www.inter-m.com